

ElaProof coated roof maintenance instructions

In order to ensure the functionality of the ElaProof coating's technical properties, we recommend checking the roof regularly, at least twice a year.

- Inspection of the ElaProof coating in spring and autumn.
- Remove all debris and leaves from roof surfaces, ducts and the rainwater system.

If you notice external damage to the coating, proceed as follows:

- Remove the damaged ElaProof coating
- Recoat the area with ElaProof H
- If necessary, use ElaProof base fabric or ElaProof ROOF reinforcement fabric

If the ElaProof coating requires washing, proceed as follows:

- Use water and a soft brush for washing
- If necessary, you can use a detergent, e.g. BioComb Puhdas Katto
- We do not recommend using a pressure washer to wash the roof. Excessive water pressure can damage the coating.

Updated: 06/2023 | MA

All the information presented above is based on research results, our current knowledge and experience. They do not remove the responsibility of the user of the product to carry out his own tests and experiments, so that all factors and conditions that may affect the installation and use of the products should be considered. No guarantees regarding the properties or suitability of the product for specific purposes can be given based on this information. All descriptions, drawings, photos, information, proportions, portion sizes, weights, etc. are indicative. We are not responsible if the product is used contrary to the instructions presented here. It is the responsibility of the user of the product to test the suitability of the product for the purpose of use. We are only responsible for the quality of the product and guarantee that it will pass our critical quality control. Product information is updated regularly, however, it is the user's responsibility to obtain the latest valid product information, which can be found at www.elaproof.com. We reserve the right to make changes. © Build Care Oy